


EPSILON 8130 SERIES

Managed 8-Port Gigabit Ethernet Switch

User Manual rev 1.0 PRELIMINARY



Revision	Date	Comment
1.0	02/15/2022	Initial Release

**FOR TECHNICAL SUPPORT
PLEASE CONTACT:**

support@diamondsystems.com

© Copyright 2022
Diamond Systems Corporation
www.diamondsystems.com

CONTENTS

1. Important Safe Handling Information	4
2. Introduction	5
2.1 Features.....	6
2.1.1 Main Feature List.....	6
2.1.2 Mechanical and Environmental.....	6
2.2 Products.....	6
2.3 Cable List.....	7
3. Functional Overview	8
3.1 Functional Block Diagram.....	8
3.2 Board Layout.....	9
4. Connector and Jumper List	10
4.1 Connector and Jumper List.....	10
4.2 Jumper Block (J15).....	10
5. Connector Pinout and Pin Description	11
5.1 Ethernet (J4-J11).....	11
5.2 Serial Interface (J12).....	11
5.3 Input Power (J14).....	11
5.4 LED Status Signals (J13).....	12
6. Thermal Solutions	13
6.1 Heat Sink.....	13
6.2 Heat Spreader.....	14
7. Command Line Interface	15
7.1 Making an Initial Connection.....	15
7.2 Login/Logout Procedures.....	15
7.3 Help Utility.....	16
7.4 Entering Commands.....	16
7.5 General Command Groups.....	16
7.5.1 IP Commands.....	16
7.5.2 MAC Commands.....	17
7.5.3 VLAN/PVLAN Commands.....	17
7.5.4 dot1x (IEEE Standard for port-based Network Access Control).....	17
7.5.5 LACP Commands.....	18
7.5.6 LLDP Commands.....	18
7.5.7 Access Management Commands.....	18
7.5.8 Access-list Commands.....	18
7.5.9 Logging Commands.....	18
7.5.10 Spanning-tree Commands.....	19
7.5.11 Green-Ethernet Commands.....	19
7.5.12 Thermal-protect Commands.....	19
7.5.13 Loop-protect Commands.....	19
7.5.14 QoS Commands.....	19
7.5.15 Privilege Commands.....	20
7.5.16 SNMP Commands.....	20
7.5.17 Sntp Commands.....	20
7.5.18 Radius Server Commands.....	21
7.5.19 Banner Commands (Defines a login banner).....	21
7.5.20 Terminal Commands.....	21
7.5.21 Reload.....	21
7.5.22 Firmware Commands.....	22
7.5.23 Ping Commands.....	22
7.5.24 Debug Commands.....	22
7.5.25 Security Commands.....	22
7.5.26 Monitor.....	22
7.6 Examples.....	23
7.6.1 IP Configuration.....	23
7.6.2 Port Configuration.....	23
7.6.3 Change Switch Password.....	23
7.6.4 Set up VLANs.....	23
7.6.5 SNMP configuration.....	24

7.6.6	Mirroring	24
7.6.7	Setup QoS	25
7.6.8	Firmware Upgrade	25
7.6.9	Factory defaults.....	25
8.	Web Interface.....	26
8.1	Examples.....	26
8.1.1	IP Configuration.....	26
8.1.2	Port Configuration.....	27
8.1.3	Change Password	28
8.1.4	Set-up VLANs	29
8.1.5	SNMP Configuration	30
8.1.6	Mirroring	31
8.1.7	Setup QoS	32
8.1.8	Web Interface Activation / Deactivation	33
8.1.9	Firmware Upgrade	33
8.1.10	Save Startup Configuration.....	33
8.1.11	Factory Defaults	34
8.1.12	Physical Reset.....	35
9.	Specifications	36
Appendix A	Supported MIBs	37
Appendix B	Upgrading Bootloader & Application Image	37
Appendix C	Changes from EPS-8100 to EPS-8130	40

1. IMPORTANT SAFE HANDLING INFORMATION



WARNING!

ESD-Sensitive Electronic Equipment

Observe ESD-safe handling procedures when working with this product.

Always use this product in a properly grounded work area and wear appropriate ESD-preventive clothing and/or accessories.

Always store this product in ESD-protective packaging when not in use.

Safe Handling Precautions

The Epsilon-8130 board contains a high density connector with many connections to sensitive electronic components. This creates many opportunities for accidental damage during handling, installation and connection to other equipment. The list here describes common causes of failure found on boards returned to Diamond Systems for repair. This information is provided as a source of advice to help you prevent damaging your Diamond (or any vendor's) boards.

ESD damage – This type of damage is usually almost impossible to detect, because there is no visual sign of failure or damage. The symptom is that the board eventually simply stops working, because some component becomes defective. Usually the failure can be identified and the chip can be replaced. To prevent ESD damage, always follow proper ESD-prevention practices when handling computer boards.

Damage during handling or storage – On some boards we have noticed physical damage from mishandling. A common observation is that a screwdriver slipped while installing the board, causing a gouge in the PCB surface and cutting signal traces or damaging components.

Another common observation is damaged board corners, indicating the board was dropped. This may or may not cause damage to the circuitry, depending on what is near the corner. Most of our boards are designed with at least 25 mils clearance between the board edge and any component pad, and ground / power planes are at least 20 mils from the edge to avoid possible shorting from this type of damage. However these design rules are not sufficient to prevent damage in all situations.

A third cause of failure is when a metal screwdriver tip slips, or a screw drops onto the board while it is powered on, causing a short between a power pin and a signal pin on a component. This can cause overvoltage / power supply problems described below. To avoid this type of failure, only perform assembly operations when the system is powered off.

Sometimes boards are stored in racks with slots that grip the edge of the board. This is a common practice for board manufacturers. However our boards are generally very dense, and if the board has components very close to the board edge, they can be damaged or even knocked off the board when the board tilts back in the rack. Diamond recommends that all our boards be stored only in individual ESD-safe packaging. If multiple boards are stored together, they should be contained in bins with dividers between boards. Do not pile boards on top of each other or cram too many boards into a small location. This can cause damage to connector pins or fragile components.

Power supply wired backwards – Our power supplies and boards are not designed to withstand a reverse power supply connection. This will destroy each IC that is connected to the power supply (i.e. almost all ICs). In this case the board will most likely will be unrepairable and must be replaced. A chip destroyed by reverse power or by excessive power will often have a visible hole on the top or show some deformation on the top surface due to vaporization inside the package. **Check twice before applying power!**

Overvoltage on analog input – If a voltage applied to an analog input exceeds the design specification of the board, the input multiplexer and/or parts behind it can be damaged. Most of our boards will withstand an erroneous connection of up to $\pm 35V$ on the analog inputs, even when the board is powered off, but not all boards, and not in all conditions.

Overvoltage on analog output – If an analog output is accidentally connected to another output signal or a power supply voltage, the output can be damaged. On most of our boards, a short circuit to ground on an analog output will not cause trouble.

Overvoltage on digital I/O line – If a digital I/O signal is connected to a voltage above the maximum specified voltage, the digital circuitry can be damaged. On most of our boards the acceptable range of voltages connected to digital I/O signals is 0-5V, and they can withstand about 0.5V beyond that (-0.5 to 5.5V) before being damaged. However logic signals at 12V and even 24V are common, and if one of these is connected to a 5V logic chip, the chip will be damaged, and the damage could even extend past that chip to others in the circuit.

2. INTRODUCTION

The Epsilon 8130 series (referred to as EPS-8130) is a rugged, managed, 8-Port Gigabit Ethernet Switch with wide power supply voltage and positive latching connectors. Epsilon-8130 offers 10/100/1000Mbps copper twisted pair ports on a PC/104 format board. A built-in microcontroller runs Layer 2+ managed software to control all switch functions. Both a web interface and an RS-232 interface are provided to enable user access to the microcontroller for configuration and monitoring. A wide-range DC power supply is built into the board to allow it to be used with industrial power sources as well as the typical embedded +5V supply. The Epsilon 8130 family is available with both heat sink and heat spreader configurations. Both configurations support full -40 to +85°C operating temperature.

EPS-8130 was designed as a compatible replacement for EPS-8100 series due to component end of life and availability issues. All features and functions of EPS-8100 are retained in EPS-8130. There should be no difficulty in using the new model in place of the old one. Please refer to Appendix C for details on the differences between the original EPS-8100 to the EPS-8130.

Layer 2+ Managed Switch

Epsilon-8130's Ethernet switch chip includes a built-in microcontroller for configuration and management. It can be accessed either through the on-board RS-232 port or one of the Ethernet ports.

Wide Power DC/DC Power Supply


Epsilon-8130 is powered through a wide voltage +5-34V DC/DC power supply input.

Rugged Design

Extended temperature operation of -40°C to +85°C is tested and guaranteed. Epsilon-8130 was designed with harsh applications in mind. Latching connectors provide increased reliability over common pin headers or RJ-45 jacks.

Software Support

The switch is ready to plug into your application without any driver installation or firmware upgrades. A web interface and a CLI provide an intuitive GUI for configuring and managing the switch. The branding and configuration of the switch are customizable as a service.



EPS-8130 with heat sink



EPS-81300-XT with heat spreader
(EPS-8100-XT shown, 8130 is similar)

2.1 Features

2.1.1 Main Feature List

- ◆ 8 10/100/1000Mbps copper Ethernet ports with nonblocking wire-speed performance
- ◆ Dual leaky bucket policers with remarking and statistics
- ◆ Jumbo frame support at all speeds
- ◆ 8K MAC addresses and 4K VLANs (IEEE 802.1Q), as well as 8K IPv4 and IPv6 multicast group support
- ◆ Flexible link aggregation support based on Layer-2 through Layer-4 information (IEEE 802.3ad)
- ◆ Multicast and broadcast storm control, as well as flooding control
- ◆ Rapid Spanning Tree protocol (RSTP) and MSTP
- ◆ 8 priorities and 8 QoS queues per port with scheduling
- ◆ Shaping/policing per queue and per port
- ◆ Multiple protocol support: IEEE 802.1d, IEEE 802.1w, IEEE 802.1s, and IEEE 802.1X
- ◆ Built-in 416MHz MIPS 24KEC microcontroller for configuration and management
- ◆ RS-232 serial port provides out-of-band management interface
- ◆ Direct UART TTL by-passing RS-232 transceiver is also supported
- ◆ Can operate autonomously or in conjunction with a host SBC
- ◆ Wide input voltage range: +5 to +36VDC input
- ◆ PC/104 form factor (3.55 x 3.775 in.)
- ◆ -40°C to +85°C (-40°F to +185°F) operating temperature

2.1.2 Mechanical and Environmental

- ◆ PC/104 compliant form factor including:
 - ◆ Board dimensions
 - ◆ Mounting holes
 - ◆ Component and heat sink height
 - ◆ -40°C to +85°C ambient operating temperature

2.2 Products


The table below lists the model number and description for the Epsilon-8130 and its associated cable kit.

Model Number	Description
EPS-8130-XT	8-Port Gigabit Ethernet Switch with heat spreader, PC/104 form factor, -40°C to +85°C operating temperature
EPS-8130	8-Port Gigabit Ethernet Switch with heat sink, PC/104 form factor, -40°C to +85°C operating temperature
C-EPS8000-KIT	Epsilon-8130 Cable Kit

2.3 Cable List

The contents of the Epsilon-8130 Cable Kit, C-EPS8000-KIT (same as EPS-8100), are shown below.

Number	Part Number	Quantity	Cable Description
1	6981052	8	Ethernet cable (1 per port)
2	6981051	1	Power cable
3	6981050	1	Serial cable



PC/104™ and PC/104-Plus™ are trademarks of the PC/104 Embedded Consortium.

All other trademarks are the property of their respective owners.

3. FUNCTIONAL OVERVIEW

3.1 Functional Block Diagram




Figure 1. Functional Block Diagram

Epsilon-8130 is an 8-Port managed Gigabit Ethernet switch module offering 10/100/1000Mbps copper twisted pair ports on a PC/104 form factor board. Epsilon-8130 operates standalone, requiring no connection to a single board computer in the stack. It contains built-in microcontroller and memory for configuration and management. The Flash memory holds dual application images along with the boot code. The SRAM is used for program execution and storing MAC addresses and other operational configuration data.

An RS-232 interface is provided to enable communication between the on-board management microcontroller and a host processor through a CLI interface. Direct UART TTL logic is also supported by by-passing RS-232 transceiver based on requirements. The microcontroller is also accessible through one of the Ethernet ports via a web management interface.

Power is provided through the +5-34VDC wide-range DC power supply built into the board, enabling use with industrial power sources.

3.2 Board Layout

The following photo shows the locations for all connectors and jumpers which are described in the next sections.




Figure 2. Epsilon-8130 Connectors and Jumpers

4. CONNECTOR AND JUMPER LIST

4.1 Connector and Jumper List

The following table summarizes the functions of Epsilon-8130's interface connectors and jumper. Refer to Figure 2 for the locations of these connectors on Epsilon-8130. Signal functions relating to all of Epsilon-8130's interface connectors are discussed in greater detail in Section 6 of this document. Other connectors and jumper blocks on Epsilon-8130 are reserved for Diamond's use only.

Connector	Function
LAN1-8	Ethernet (x8)
RS-232	RS-232 Serial Interface
LED	LED Status Signals and Resets
Power In	Wide voltage power input
J15	Jumper Block J15

4.2 Jumper Block (J15)

The following table summarizes the functions of Epsilon-8130's jumper block, J15. Refer to the Figure 2 for the location of J15 on Epsilon-8130.

Position	Function	IN	OUT
RST	Board Reset	Reset	<i>Out of reset</i>
DFLT	Default	Restore Factory settings	<i>Save configuration settings</i>
DIS-COM	COM SD	RS-232 Driver disabled	<i>RS-232 Driver enabled</i>
<i>*Default Mode</i>			

5. CONNECTOR PINOUT AND PIN DESCRIPTION

5.1 Ethernet (J4-J11)

Epsilon-8130 contains eight right-angle, locking pin headers for the eight Ethernet ports. Each port has the same style and pin out. Each signal is associated with a particular color inside of the Diamond Systems cable part number 6981052. The color coding for this cable follows the TIA/EIA 568B standard.

DD+	1	2	DD-
DC+	3	4	DC-
DB+	5	6	DB-
DA+	7	8	DA-
Gnd	9	10	Gnd

Connector Type: JST PUD series 2mm dual row right-angle, locking pin header with tin plating

Mating Connector: JST Sales America PUDP-10V-S housing with SPUD-002T-P0.5 terminals

Mating Cable: DSC part number 6981052 (Note: the ground pins on the board connector are not used on this cable.)

5.2 Serial Interface (J12)

Epsilon-8130 contains an RS-232 connector, J12, which connects the on-board microcontroller to an external serial port.

1	Ground
2	TxD Out
3	RxD In

Connector Type: 2mm single row right-angle, locking pin header with tin plating

Mating Connector: Molex Connector 35507-0300 housing with 50212-8100 terminals

Mating Cable: DSC part number 6981052 (Note: the ground pins on the board connector are not used on this cable.)

5.3 Input Power (J14)

Input power is supplied either through the dedicated 4-pin connector (J14). The pin out for J14 is:

1	V In
2	Ground
3	Ground
4	V In

Connector Type: 2mm single row right-angle, locking pin header with tin plating

Mating Connector: Molex Connector 35507-0400 housing with 50212-8100 terminals

Mating Cable: DSC part number 6981052 (Note: the ground pins on the board connector are not used on this cable.)

5.4 LED Status Signals (J13)

Connector J13 provides access to the Ethernet LED signals for each of the eight ports. This connector has duplicate connections for Reset control input. LEDs may be directly connected to these signals without requiring any current-limiting resistors.

The on board activity LED is a green LED (LTST-C190GKT) with a typical forward voltage of 2.1V and a maximum of 2.6V with a 20mA If. The on board speed LED is a Yellow LED (LTST-C190YKT) with the same characteristics. The control signal is capable of sinking a maximum of 18mA. The series resistor is 330 ohms, which gives an If of about 3.6mA. When an LED is connected to connector J13, it is in parallel with the on board LED. If the external LED has about the same forward voltage, the current will be cut in half. If the external LED has a lower forward voltage, it will dominate the on-board LED and be brighter. Therefore, if the external LED is not bright enough use an external LED with a lower forward voltage.

Reset: Causes a reset of the switch when connected to ground.


SW_GPIO1 and SW_GPIO2 - provide control for user defined LEDs.

Port 2 Activity	1	2	Ground
Ground	3	4	Port 2 Speed
Port 4 Activity	5	6	Port 4 Speed
Port 6 Activity	7	8	Ground
Ground	9	10	Port 6 Speed
Port 8 Activity	11	12	Port 8 Speed
Port 7 Speed	13	14	Ground
Ground	15	16	Port 7 Activity
Port 5 Speed	17	18	Port 5 Activity
Port 3 Speed	19	20	Ground
Ground	21	22	Port 3 Activity
Port 1 Speed	23	24	Port 1 Activity
#Default	25	26	#Reset
SW_GPIO1	27	28	SW_GPIO0
3.3V	29	30	3.3V
	31	32	
	33	34	

Connector Type: 2mm dual row right-angle, through hole, 34 circuits, pin header. 877603416 from Molex

Mating Cable: DSC 6981509 cable can be used. This is not a part of cable kit. A common 2mm pitch 2x17 ribbon cable can also be used.


The following diagram shows how to connect external LEDs to connector J13:



6. THERMAL SOLUTIONS

6.1 Heat Sink


Model EPS-8130 contains a heat sink for cooling. The heat sink is positively affixed to the board with 2 screws, and it contains a thermal pad to contact the Ethernet switch IC. The total height conforms to the height limitations for a PC/104 form factor board (11.2mm / 0.435" above the top surface of the PCB). Although the size of the heat sink is small, it is capable of enabling the EPS-8130 to operate over the full industrial temperature range of -40 to +85°C, as long as there is free air above it (no other board should be mounted over the heat sink).



6.2 Heat Spreader

Model EPS-8130-XT contains a heat spreader which serves as both a cooling method and a mounting method for the board. The heat spreader is the same size as the board and uses a thermal pad to contact the Ethernet switch IC. The I/O connectors overhang the board and heat spreader so they can still be accessed. The heat spreader is intended for direct mounting to the inner surface of the system enclosure. Thermal grease may be applied to the junction if desired. The heat spreader enables the EPS-8130 to operate over the full industrial temperature range of -40 to +85°C.

Custom heat spreaders can be designed to meet particular application requirements. Examples include a larger size to enable mounting from the interior or a different mounting hole pattern.



7. COMMAND LINE INTERFACE

The command line interface (CLI) is a modal, line-based interface with no screen editing features where commands are executed immediately upon end-of-line. The CLI can be accessed directly via the serial connection. The user must log in before CLI commands can be executed.

7.1 Making an Initial Connection

Serial line configuration:

```
38400 baud
8 bit data
No parity
1 stop bit
```

Login information

```
Username: admin
Password: {none}
```

The board is shipped with an IP address of 192.168.1.60. This allows the WEB interface to be accessed at that address.

The IP address, mask and gateway must be set according to your environment, or you can enable IP and DHCP if your environment includes a DHCP server. For example:

```
# configure terminal
(config)# interface vlan 1
(config-if-vlan)# ip address dhcp
(config-if-vlan)# end
```

Below example depicts configuration of static IP address,

```
# configure terminal
(config)# interface vlan 1
(config-if-vlan)# ip address 192.168.1.60 255.255.0.0
(config-if-vlan)# end
```

Display the IP address to confirm:

```
# show ip interface brief
Vlan Address                Method  Status
-----
  1 192.168.1.60             Manual  UP
#
```

7.2 Login/Logout Procedures

To get access to the CLI you must login by entering a username and password. You will automatically be queried about the password.

The password is configurable. You may logout at any time and at any context level using the exit command

7.3 Help Utility

You may get help by pressing the ? key or entering *help*. The help info depends on the context:

- At top level, a list of command groups is displayed.
- At group level, a list of the command syntaxes for the current group is displayed.
- If the help command is issued for a specific command, the command syntax and a description of the command are shown.

7.4 Entering Commands

- Commands are not case-sensitive.
- You may use the horizontal arrow-keys ← and → to move the cursor within the command you are entering.
- You may use the backspace key (provided you are using a terminal that sends the BS (8) character when the backspace key is pressed) to delete chars from the command you are entering.
- You may use the vertical arrow-keys ↑ and ↓ to scroll through a command history buffer of the latest 20 commands issued.

7.5 General Command Groups

The following groups of general commands are available in the command line interface (CLI).

```
# ?
clear          Reset functions
configure     Enter configuration mode
copy          Copy from source to destination
debug         Debugging functions
delete        Delete one file in flash: file system
dir           Directory of all files in flash: file system
disable       Turn off privileged commands
do            To run exec commands in config mode
dot1x         IEEE Standard for port-based Network Access Control
enable        Turn on privileged commands
exit          Exit from EXEC mode
firmware      Firmware upgrade/swap
help          Description of the interactive help system
ip            IPv4 commands
logout        Exit from EXEC mode
more          Display file
no            Negate a command or set its defaults
ping          Send ICMP echo messages
reload        Reload system.
send          Send a message to other tty lines
show          Show running system information
terminal      Set terminal line parameters
#
```

7.5.1 IP Commands

```
(config)# ip http secure-redirect
```

```
(config)# ip http secure-server
(config)# ip igmp snooping
(config)# ip igmp snooping vlan <v_vlan_list>
(config)# ip igmp unknown-flooding
(config)# ip route <v_ipv4_addr> <v_ipv4_netmask> <v_ipv4_gw>
(config)# ip dhcp retry interface vlan <vlan_id>
(config)# no ip http secure-redirect
(config)# no ip http secure-server
(config)# no ip igmp snooping
(config)# no ip igmp snooping vlan [ <v_vlan_list> ]
(config)# no ip igmp unknown-flooding
(config)# no ip route <v_ipv4_addr> <v_ipv4_netmask> <v_ipv4_gw>
# clear ip arp
# clear ip igmp snooping [ vlan <v_vlan_list> ] statistics
# clear ip statistics [ system ] [ interface vlan <v_vlan_list> ] [ icmp ] [ icmp-msg <type> ]
# show ip arp
# show ip http server secure status
# show ip igmp snooping [ vlan <v_vlan_list> ] [ group-database [ interface ( <port_type> [ <v_port_type_list> ] ) ] [ sfm-information ] ] [ detail ]
# show ip igmp snooping mrouter [ detail ]
# show ip interface brief
# show ip route
# show ip statistics [ system ] [ interface vlan <v_vlan_list> ] [ icmp ] [ icmp-msg <type> ]
```

7.5.2 MAC Commands

```
(config)# mac address-table aging-time <v_0_10_to_1000000>
(config)# mac address-table static <v_mac_addr> vlan <v_vlan_id> interface ( <port_type> [ <v_port_type_list> ] )
(config)# no mac address-table aging-time
(config)# no mac address-table aging-time <v_0_10_to_1000000>
(config)# no mac address-table static <v_mac_addr> vlan <v_vlan_id> interface ( <port_type> [ <v_port_type_list> ] )
# clear mac address-table
# show mac address-table [ conf | static | aging-time | { { learning | count } [ interface ( <port_type> [ <v_port_type_list> ] ) ] } | { address <v_mac_addr> [ vlan <v_vlan_id> ] } | vlan <v_vlan_id_1> | interface ( <port_type> [ <v_port_type_list_1> ] ) ]
```

7.5.3 VLAN/PVLAN Commands

```
(config)# interface vlan <vlist>
(config)# no interface vlan <vlist>
(config)# no vlan { { ethertype s-custom-port } | <vlan_list> }
(config)# vlan <vlist>
(config)# vlan ethertype s-custom-port <etype>
# show interface vlan [ <vlist> ]
# show pvlan [ <pvlan_list> ]
# show pvlan isolation [ interface ( <port_type> [ <plist> ] ) ]
# show vlan [ id <vlan_list> | name <name> | brief ]
# show vlan status [ interface ( <port_type> [ <plist> ] ) ] [ combined | admin | nas | mvr | voice-vlan | mstp | erps | vcl | evc | gvrp | all | conflicts ]
```

7.5.4 dot1x (IEEE Standard for port-based Network Access Control)

```
(config)# dot1x authentication timer inactivity <v_10_to_100000>
(config)# dot1x authentication timer re-authenticate <v_1_to_3600>
```

```
(config)# dot1x re-authentication
(config)# dot1x system-auth-control
(config)# dot1x timeout quiet-period <v_10_to_1000000>
(config)# dot1x timeout tx-period <v_1_to_65535>
(config)# no dot1x authentication timer inactivity
(config)# no dot1x authentication timer re-authenticate
(config)# no dot1x re-authentication
(config)# no dot1x system-auth-control
(config)# no dot1x timeout quiet-period
(config)# no dot1x timeout tx-period
# clear dot1x statistics [ interface ( <port_type> [ <v_port_type_list> ] ) ]
# dot1x initialize [ interface ( <port_type> [ <plist> ] ) ]
# show dot1x statistics { eapol | radius | all } [ interface ( <port_type> [ <v_port_type_list> ] ) ]
# show dot1x status [ interface ( <port_type> [ <v_port_type_list> ] ) ] [ brief ]
```

7.5.5 LACP Commands

```
(config)# lacp system-priority <v_1_to_65535>
(config)# no lacp system-priority <v_1_to_65535>
# clear lacp statistics
# show lacp { internal | statistics | system-id | neighbour }
```

7.5.6 LLDP Commands

```
(config)# lldp holdtime <val>
(config)# lldp reinit <val>
(config)# lldp timer <val>
(config)# lldp transmission-delay <val>
(config)# no lldp holdtime
(config)# no lldp reinit
(config)# no lldp timer
(config)# no lldp transmission-delay
# clear lldp statistics
# show lldp eee [ interface ( <port_type> [ <v_port_type_list> ] ) ]
# show lldp neighbors [ interface ( <port_type> [ <v_port_type_list> ] ) ]
# show lldp statistics [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

7.5.7 Access Management Commands

```
(config)# access management <access_id> <access_vid> <start_addr> [ to <end_addr> ] { [ web ] [ snmp ] [ telnet ] | all }
(config)# no access management
(config)# no access management <access_id_list>
# clear access management statistics
# show access management [ statistics | <access_id_list> ]
```

7.5.8 Access-list Commands

```
(config)# access-list rate-limiter [ <rate_limiter_list> ] { pps <pps_rate> | 100pps <pps100_rate> | kpps <kpps_rate> | 100kbps <kpbs100_rate> }
(config)# default access-list rate-limiter [ <rate_limiter_list> ]
(config)# no access-list ace <ace_list>
# clear access-list ace statistics
# show access-list [ interface [ ( <port_type> [ <v_port_type_list> ] ) ] ] [ rate-limiter [ <rate_limiter_list> ] ] [ ace statistics [ <ace_list> ] ]
# show access-list ace-status [ static ] [ link-oam ] [ loop-protect ] [ dhcp ] [ ptp ] [ upnp ] [ arp-inspection ] [ evc ] [ mep ] [ ipmc ] [ ip-source-guard ] [ ip-mgmt ] [ conflicts ] [ switch <switch_list> ]
```

7.5.9 Logging Commands

```
(config)# logging host <v_word45>
(config)# logging level { info | warning | error }
```

```
(config)# logging on
(config)# no logging host
(config)# no logging on

# clear logging [ info ] [ warning ] [ error ] [ switch <switch_list> ]
# show logging <log_id> [ switch <switch_list> ]
# show logging [ info ] [ warning ] [ error ] [ switch <switch_list> ]
```

7.5.10 Spanning-tree Commands

```
(config)# spanning-tree aggregation
(config)# spanning-tree edge bpdu-filter
(config)# spanning-tree edge bpdu-guard
(config)# spanning-tree mode { stp | rstp | mstp }
(config)# spanning-tree recovery interval <interval>
(config)# spanning-tree transmit hold-count <holdcount>
(config)# no spanning-tree edge bpdu-filter
(config)# no spanning-tree edge bpdu-guard
(config)# no spanning-tree mode
(config)# no spanning-tree recovery interval
(config)# no spanning-tree transmit hold-count

# clear spanning-tree { { statistics [ interface ( <port_type> [ <v_port_type_list> ] ) ] } | { detected-protocols [
interface ( <port_type> [ <v_port_type_list_1> ] ) ] } }
# show spanning-tree [ summary | active | { interface ( <port_type> [ <v_port_type_list> ] ) } | { detailed [ interface
( <port_type> [ <v_port_type_list_1> ] ) ] } | { mst [ configuration | { <instance> [ interface ( <port_type> [
<v_port_type_list_2> ] ) ] } ] } ] }
```

7.5.11 Green-Ethernet Commands

```
(config)# green-ethernet eee optimize-for-power
(config)# green-ethernet led interval <v_0_to_24> intensity <v_0_to_100>
(config)# green-ethernet led on-event { [ link-change <v_0_to_65535> ] [ error ] } *1
(config)# no green-ethernet eee optimize-for-power
(config)# no green-ethernet led interval <0~24>
(config)# no green-ethernet led on-event [ link-change ] [ error ]
# show green-ethernet [ interface ( <port_type> [ <port_list> ] ) ]
# show green-ethernet eee [ interface ( <port_type> [ <port_list> ] ) ]
# show green-ethernet energy-detect [ interface ( <port_type> [ <port_list> ] ) ]
# show green-ethernet short-reach [ interface ( <port_type> [ <port_list> ] ) ]
```

7.5.12 Thermal-protect Commands

```
(config)# no thermal-protect prio <prio_list>
(config)# thermal-protect prio <prio_list> temperature <new_temp>
# show thermal-protect [ interface ( <port_type> [ <port_list> ] ) ]
```

7.5.13 Loop-protect Commands

```
(config)# loop-protect
(config)# loop-protect shutdown-time <t>
(config)# loop-protect transmit-time <t>
(config)# no loop-protect
(config)# no loop-protect shutdown-time
(config)# no loop-protect transmit-time
# show loop-protect [ interface ( <port_type> [ <plist> ] ) ]
```

7.5.14 QoS Commands

```
(config)# no qos qce <qce_id_range>
(config)# no qos storm { unicast | multicast | broadcast }
```

```
(config)# qos storm { unicast | multicast | broadcast } { { <rate> [ kfps ] } | { 1024 kfps } }
# show qos [ { interface [ ( <port_type> [ <port> ] ) ] } | wred | { maps [ dscp-cos ] [ dscp-ingress-translation ] [
dscp-classify ] [ cos-dscp ] [ dscp-egress-translation ] } | storm | { qce [ <qce> ] } ]
```

7.5.15 Privilege Commands

```
(config)# privilege { exec | configure | config-vlan | line | interface | if-vlan | ipmc-profile | snmps-host | stp-aggr |
dhcp-pool | rfc2544-profile } level <privilege> <cmd>
(config)# no privilege { exec | configure | config-vlan | line | interface | if-vlan | ipmc-profile | snmps-host | stp-aggr |
dhcp-pool | rfc2544-profile } level <0-15> <cmd>
# show privilege
```

7.5.16 SNMP Commands

```
(config)# snmp-server
(config)# snmp-server access <group_name> model { v1 | v2c | v3 | any } level { auth | noauth | priv } [ read
(config)# <view_name> ] [ write <write_name> ]
(config)# snmp-server community v2c <comm> [ ro | rw ]
(config)# snmp-server community v3 <v3_comm> [ <v_ipv4_addr> <v_ipv4_netmask> ]
(config)# snmp-server contact <v_line255>
(config)# snmp-server engine-id local <engineID>
(config)# snmp-server host <conf_name>
(config)# snmp-server location <v_line255>
(config)# snmp-server security-to-group model { v1 | v2c | v3 } name <security_name> group <group_name>
(config)# snmp-server trap
(config)# snmp-server user <username> engine-id <engineID> [ { md5 <md5_passwd> | sha <sha_passwd> } [
priv { des | aes } <priv_passwd> ] ]
(config)# snmp-server version { v1 | v2c | v3 }
(config)# snmp-server view <view_name> <oid_subtree> { include | exclude }
(config)# no snmp-server
(config)# no snmp-server access <group_name> model { v1 | v2c | v3 | any } level { auth | noauth | priv }
(config)# no snmp-server community v2c
(config)# no snmp-server community v3 <community>
(config)# no snmp-server contact
(config)# no snmp-server engine-id local
(config)# no snmp-server host <conf_name>
(config)# no snmp-server location
(config)# no snmp-server security-to-group model { v1 | v2c | v3 } name <security_name>
(config)# no snmp-server trap
(config)# no snmp-server user <username> engine-id <engineID>
(config)# no snmp-server version
(config)# no snmp-server view <view_name> <oid_subtree>
# show snmp
# show snmp access [ <group_name> { v1 | v2c | v3 | any } { auth | noauth | priv } ]
# show snmp community v3 [ <community> ]
# show snmp host [ <conf_name> ] [ system ] [ switch ] [ interface ] [ aaa ]
# show snmp mib context
# show snmp mib if mib ifIndex
# show snmp security-to-group [ { v1 | v2c | v3 } <security_name> ]
# show snmp user [ <username> <engineID> ]
# show snmp view [ <view_name> <oid_subtree> ]
```

7.5.17 SNTP Commands

```
(config)# sntp
(config)# sntp server ip-address { <ipv4_var> }
(config)# no sntp
```

```
(config)# no snmp server
# show snmp status
```

7.5.18 Radius Server Commands

```
(config)# radius-server attribute 32 <id>
(config)# radius-server attribute 4 <ipv4>
(config)# radius-server deadtime <minutes>
(config)# radius-server host <host_name> [ auth-port <auth_port> ] [ acct-port <acct_port> ] [ timeout <seconds> ]
[ retransmit <retries> ] [ key <key> ]
(config)# radius-server key <key>
(config)# radius-server retransmit <retries>
(config)# radius-server timeout <seconds>
(config)# no radius-server attribute 32
(config)# no radius-server attribute 4
(config)# no radius-server deadtime
(config)# no radius-server host <host_name> [ auth-port <auth_port> ] [ acct-port <acct_port> ]
(config)# no radius-server key
(config)# no radius-server retransmit
(config)# no radius-server timeout
# show radius-server [ statistics ]
# show running-config [ all-defaults ]
# show running-config feature <feature_name> [ all-defaults ]
# show running-config interface ( <port_type> [ <list> ] ) [ all-defaults ]
# show running-config interface vlan <list> [ all-defaults ]
# show running-config line { console | vty } <list> [ all-defaults ]
# show running-config vlan <list> [ all-defaults ]
```

7.5.19 Banner Commands (Defines a login banner)

```
(config)# banner [ motd ] <banner>
(config)# banner exec <banner>
(config)# banner login <banner>
(config)# no banner [ motd ]
(config)# no banner exec
(config)# no banner login
```

7.5.20 Terminal Commands

```
(config)# no terminal editing
(config)# no terminal exec-timeout
(config)# no terminal history size
(config)# no terminal length
(config)# no terminal width
# terminal editing
# terminal exec-timeout <min> [ <sec> ]
# terminal help
# terminal history size <history_size>
# terminal length <lines>
# terminal width <width>
```

7.5.21 Reload

```
reload { { cold | warm } [ sid <usid> ] } | { defaults [ keep-ip ] }
```

7.5.22 Firmware Commands

```
# firmware swap
# firmware upgrade <tftpserver_path_file>
```

7.5.23 Ping Commands

```
# ping ip <v_ip_addr> [ repeat <count> ] [ size <size> ] [ interval <seconds> ]
```

7.5.24 Debug Commands

```
(config)# no debug prompt
(config)# line { <0~16> | console 0 | vty <0~15> }
# no debug prompt
# debug prompt <debug_prompt>
```

7.5.25 Security Commands

```
(config)# no aaa authentication login { console | telnet | ssh | http }
(config)# password encrypted <encry_password>
(config)# password none
(config)# password unencrypted <password>
(config)# enable password [ level <priv> ] <password>
(config)# enable secret { 0 | 5 } [ level <priv> ] <password>
(config)# no enable password [ level <priv> ]
(config)# no enable secret { [ 0 | 5 ] } [ level <priv> ]
# show aaa
# show port-security port [ interface ( <port_type> [ <v_port_type_list> ] ) ]
# show port-security switch [ interface ( <port_type> [ <v_port_type_list> ] ) ]
(config)# aaa authentication login { console | telnet | ssh | http } { { local | radius | tacacs } [ { local | radius | tacacs } ] [ { local | radius | tacacs } ] }
```

7.5.26 Monitor

```
(config)# monitor destination interface <port_type> <in_port_type>
(config)# monitor source { { interface ( <port_type> [ <v_port_type_list> ] ) } | { cpu [ <cpu_switch_range> ] } } {
both | rx | tx }
(config)# no monitor destination
(config)# no monitor source { { interface ( <port_type> [ <v_port_type_list> ] ) } | { cpu [ <cpu_switch_range> ] } }
```

7.6 Examples

7.6.1 IP Configuration

Below example depicts configuration of static IP address,

```
# configure terminal
(config)# interface vlan 1
(config-if-vlan)# ip address 192.168.1.60 255.255.0.0
(config-if-vlan)# end
```

Display the IP address to confirm:

```
# show ip interface brief
Vlan Address                Method  Status
-----
  1 192.168.1.60            Manual  UP
#
```

7.6.2 Port Configuration

Individual ports can be configured to different speed. Following example shows configuring speed as 100 Mbps for port 1.

```
# configure terminal
(config)# interface GigabitEthernet 1/1
(config-if)# speed ?
  10          10Mbps
  100         100Mbps
  1000        1Gbps
  auto        Auto negotiation
(config-if)# speed 100
(config-if)# end
#
```

7.6.3 Change Switch Password

Following example shows setting of new password,

```
# configure terminal
(config)# password unencrypted <password>
(config)# exit
#
```

7.6.4 Set up VLANs

Virtual LANs (VLANs) are used to divide the network into separate logical areas. VLANs can also be considered as broadcast domains.

Following example shows setting up VLAN2 and VLAN3 with switch port mode set to access.

```
#configure terminal
(config)# vlan 2
(config)# vlan 3
```

Set access port, in this case it's assumed that port 1~3 are connected to PC. The PVID of each port is different.

```
#configure terminal
(config)# interface GigabitEthernet 1/2
(Config-if)# switchport mode access
(Config-if)# switchport access vlan 2
(config)# exit
(config)# interface GigabitEthernet 1/3
(Config-if)# switchport mode access
(Config-if)# switchport access vlan 3
(config)# exit
```

To verify created VLAN

```
# show vlan
VLAN  Name                               Interfaces
----  -
1     default                                Gi 1/1,4-8
2     VLAN0002                               Gi 1/2
3     VLAN0003                               Gi 1/3
```

As shown above, VLAN2 is created with the name VLAN0002 and a port 2 assigned to VLAN2. Similarly port 3 assigned to VLAN0003. Remaining ports 1 & 4 to 8 are by default assigned to VLAN 1

7.6.5 SNMP configuration

Following example depicts the configuration of SNMP,

To enable the SNMP mode operation

```
# configure terminal
(config)# snmp-server
(config)# exit
#
```

SNMP Trap configuration,

```
# configure terminal
(config)# snmp-server host Example
(config-snmp-host)# host 192.168.1.20
(config-snmp-host)# no shutdown
(config-snmp-host)# exit
(config)# exit
#
```

7.6.6 Mirroring

For debugging network problems or monitoring network traffic, the switch system can be configured to mirror frame from multiple ports to a mirror port. Following example depicts Mirror traffic of Port 2 and 3 (Rx) & 4 to 8 (Rx) to Port 1.

```
# configure terminal
(config)# monitor destination interface GigabitEthernet 1/1
(config)# monitor source interface GigabitEthernet 1/2-3 rx
(config)# monitor source interface GigabitEthernet 1/4-8 tx
```

7.6.7 Setup QoS

Quality of Service (QoS) refers to the capability of a network to provide better service to selected network traffic over various technologies, including Frame Relay, Asynchronous Transfer Mode (ATM), Ethernet and 802.1 networks, SONET, and IP-routed networks that may use any or all of these underlying technologies.

Following example shows setting up the QoS, all traffic coming on port 1 is mapped to QoS class (CoS) 2 and PCP is set as 1.

```
# configure terminal
(config)# interface GigabitEthernet 1/1
(config-if)# qos cos 2
(config-if)# qos pcp 1
(config-if)# end
```

7.6.8 Firmware Upgrade

A new WebStax image can be downloaded using the CLI. Copy the Epsilon-8100.dat file to a TFTP server and use the firmware upgrade command to download the file.

```
# firmware upgrade tftp://<ip_address>/<path>/Epsilon-8100.dat
#
```

7.6.9 Factory defaults

User can reset the configuration of the switch by below command. Only the IP configuration is retained.

```
# reload defaults
#
```

Note: To load the factory default configuration including the IP address, follow steps explained in section 7.1.11

8. WEB INTERFACE

The web interface offers an alternate user interface to the CLI. The web interface is in-band and requires use of one of the Ethernet ports. This port provides simultaneous web management and normal usage. The same commands with the same functionality can be accessed via either interface. From the WEB interface it is possible to, among other things:


- Set port mode
- Enable/disable flow control
- Configure simple port-based VLAN
- Configure aggregation groups
- Configure LACP parameters
- Configure QoS
- Configure SNMP
- Mirroring
- Read and clear statistics counters
- Monitor LACP status
- Configure and monitor 802.1X
- Configure and monitor IGMP snooping (if defined for switch device)
- Configure source-IP address and DHCP server filter
- Upgrade software

8.1 Examples

8.1.1 IP Configuration

IP address of the switch can be configured as follows:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Configuration -> System -> IP
3. Modify the IP Address in IPv4 Address column (refer to figure below)
4. Click on Save
5. Navigate to Maintenance -> Configuration -> Save Startup-Config and click on Save Configuration



The screenshot displays the web interface for an Epsilon-8100™ 8-Port Gigabit Ethernet Switch, Software version 2.0.0. The left sidebar shows a navigation menu with categories like Configuration, Monitor, and Diagnostics. The main content area is titled 'IP Configuration' and includes a 'Mode' dropdown set to 'Host'. Below this is the 'IP Interfaces' section, which contains a table with the following data:

Delete	VLAN	DHCPv4			IPv4	
		Enable	Fallback	Current Lease	Address	Mask Length
<input type="checkbox"/>	1	<input type="checkbox"/>	0		192.168.1.1	24

Below the table are buttons for 'Add Interface', 'Add Route', 'Save', and 'Reset'. The 'Add Route' button is highlighted with a red arrow. The 'Save' button is also highlighted with a red arrow.

Figure 3 – IP Configuration

8.1.2 Port Configuration

Individual ports can be configured as follows:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Configuration -> Ports
3. Each port can be set for one of the following configurations
 - a. Disabled – Disables the switch port operation
 - b. Auto – Port auto negotiating speed with the link partner and selects the highest speed that is compatible with the link partner
 - c. 10 Mbps HDX – Forces the cu port in 10Mbps half-duplex mode
 - d. 10 Mbps FDX – Forces the cu port in 10Mbps full-duplex mode
 - e. 100 Mbps HDX – Forces the cu port in 100Mbps half-duplex mode
 - f. 100 Mbps FDX – Forces the cu port in 100Mbps full duplex mode
 - g. 1 Gbps FDX – Forces the port in 1Gbps full duplex
4. After port configuration is done click on save
5. To save these settings permanently navigate to Maintenance -> Configuration -> Save Startup-config click on Save startup configuration

The screenshot shows the web interface for the Epsilon-8100 8-Port Gigabit Ethernet Switch. The main content area is titled "Port Configuration" and contains a table with the following columns: Port, Description, Link, Speed (Current, Configured), Adv Duplex (Fdx, Hdx), Adv speed (10M, 100M, 1G), Flow Control (Enable, Curr Rx, Curr Tx), Maximum Frame Size, Excessive Collision Mode, and Frame Length Check. The table lists 8 ports, all of which are currently "Down". A dropdown menu is open for the "Configured" speed column of port 8, showing options: Disabled, Auto, 10Mbps HDX, 10Mbps FDX, 100Mbps HDX, 100Mbps FDX, and 1Gbps FDX. The "1Gbps FDX" option is selected. Below the table are "Save" and "Reset" buttons. A "Refresh" button is located in the top right corner of the table area.

Figure 4 – Port configuration

8.1.3 Change Password

The switch login password can be changed as follows:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Configuration -> Security -> Password
3. Enter the Old password and New Password and click on Save (refer to figure below)
4. Navigate to Maintenance -> Configuration -> Save Startup-Config and click on Save Configuration




Figure 5 – System Password Configuration

8.1.4 Set-up VLANs

The following example shows the configuration of a VLAN:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Configuration -> VLANS
 - a. In the allowed access VLANs enter number of LANs to be created. In this example 1-3, that creates VLAN2 and VLAN3
 - b. By default mode is access, it can be changed to trunk or hybrid by changing Mode drop down list
 - c. Assign a ports to the virtual LANs by changing the values in the Port VLAN column (refer to figure below)
 - d. Click on Save to save the VLAN configuration
 - e. To save VLAN settings permanently navigate to Maintenance -> Configuration -> Save startup-config click on save startup configuration




Figure 6 – VLAN Configuration

After saving the VLAN configuration, VLAN membership status can be verified as follows:

1. Navigate to Monitor -> VLANS -> Membership (refer to figure below)
2. Ports 1 & 4 to 8 assigned to VLAN ID 1, Port 2 is assigned to VLAN ID 2 and Port 4 is assigned to VLAN ID 3



Figure 7 – VLAN Membership Status for Combined users

8.1.5 SNMP Configuration


The following procedure shows the SNMP configuration:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Security -> Switch -> SNMP -> System, and Enable the Mode and set the SNMP version (example: SNMP v1, SNMP v2c & SNMP v2c)

The following procedure shows the SNMP Trap configuration:

Note: if the software version is 2.0.0, it is not possible to enter trap destination address from web UI. Trap address can be configured using commands as explained in the section 6.6.5.

1. Navigate to Security -> Switch -> SNMP -> Trap and click on Add new Entry
2. Make the SNMP Trap configuration as follows and click on save



Epsilon-8100™ 8-Port Gigabit Ethernet Switch
Software version 1.0.1

SNMP Trap Configuration

Trap Config Name	Example
Trap Mode	Enabled
Trap Version	SNMP v2c
Trap Community	Public
Trap Destination Address	192.168.1.20
Trap Destination Port	162
Trap Inform Mode	Disabled
Trap Inform Timeout (seconds)	3
Trap Inform Retry Times	5
Trap Probe Security Engine ID	Enabled
Trap Security Engine ID	
Trap Security Name	None

SNMP Trap Event

System	<input type="checkbox"/> * <input type="checkbox"/> Warm Start <input type="checkbox"/> Cold Start
Interface	Link up <input checked="" type="radio"/> none <input type="radio"/> specific <input type="radio"/> all switches *Link down <input checked="" type="radio"/> none <input type="radio"/> specific <input type="radio"/> all switches LLDP <input checked="" type="radio"/> none <input type="radio"/> specific <input type="radio"/> all switches
AAA	<input type="checkbox"/> * <input type="checkbox"/> Authentication Fail
Switch	<input type="checkbox"/> * <input type="checkbox"/> STP <input type="checkbox"/> RMON

Save Reset

Figure 8 – SNMP Trap configuration

3. The trap configuration is displayed as follows:

Enable the Mode and click on Save to save the trap configuration.




Figure 9 – Trap configuration

8.1.6 Mirroring

For debugging network problems or monitoring network traffic, the switch system can be configured to mirror frame from multiple ports to a mirror port. The following example shows Mirror traffic of Port 1 (Tx) & 2(Rx) to Port 6.

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Configuration -> Mirroring (Refer below Figure)




Figure 10 – Mirroring Configuration

3. Click on Save to save the mirroring configuration.

Other Mirroring options -

Port to mirror also known as the mirror port. Frames from ports that have either source (rx) or destination (tx) mirroring enabled are mirrored on this port. Disabled disables mirroring.

Mirror Mode Configuration

1. Rx only - Frames received on this port are mirrored on the mirror port. Frames transmitted are not mirrored.
2. Tx only - Frames transmitted on this port are mirrored on the mirror port. Frames received are not mirrored.
3. Disabled - Neither frames transmitted nor frames received are mirrored.
4. Enabled - Frames received and frames transmitted are mirrored on the mirror port.

8.1.7 Setup QoS

Basic QoS classification configuration can be done per port. Ingress traffic coming on each port can be assigned to a QoS class (CoS), PCP, DPL and DEI.

The following example shows the QoS ingress port classification:

All traffic coming on port 1 is mapped to Cos 2 and PCP is set as 1.

Web GUI Configuration: (Navigate to Configuration ->QoS->Port Classification)




Figure 11 – QoS Ingress Port Classification

8.1.8 Web Interface Activation / Deactivation

The web interface can be activated and deactivated through either the command line interface or the web Control Panel.

Using the Control Panel, in the Configuration/Security/Switch/Access Management Configuration screen, first ensure the mode is set to Disabled as shown below. This is the default mode. If it is not set to Disabled, set it as Disabled and click Save.

This configuration should be stored on the switch with the following CLI command:

#copy startup-config flash:{filename}

To disable web access of the switch, in the Control Panel navigate to the Configuration/Security/Switch/Access Management Configuration screen, change the mode to Enabled and click Save.

Now there is no access to the switch using the web interface. To store this configuration in flash as the standard configuration on startup, enter the following command in the CLI:

#copy running-config startup-config

To allow web access of the switch in the future, enter the following commands in the CLI:

#copy startup-config flash:backup_config

#copy flash:{filename} startup-config

Then reboot the switch.

8.1.9 Firmware Upgrade

The following section shows the steps necessary to upgrade the firmware:

1. Connect to the web interface of EPS-8130 switch and navigate to Maintenance -> Software -> Upload (as shown in the figure below)
2. Choose Epsilon-8100.dat file and click on upload

The existing firmware is erased and new firmware loaded. Once the upgrade completes the switch reboots automatically.




Figure 12 – Firmware Upgrade

8.1.10 Save Startup Configuration

This copies running-config to startup-config, thereby ensuring that the currently active configuration will be used at the next reboot. The following example shows the Save Startup configuration:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to Maintenance -> Configuration -> Save Startup-Config (refer to the figure below)
3. Click on Save Configuration




Figure 13 – Saving Startup Configuration

8.1.11 Factory Defaults

A user can reset the configuration of the switch on this page. Only the IP configuration is retained. The new configuration is available immediately. The following procedure shows the steps for restoring the factory defaults:

1. Connect to the web interface of EPS-8130 switch
2. Navigate to maintenance -> Factory defaults
3. Click on Yes for an confirmation message (refer to the figure below)




Figure 14 – Restore Factory defaults

The switch can also be reset to the factory default settings by connecting an Ethernet cable between ports 1 & 2 and powering on the switch. The default configuration is loaded, but not restored. To save a loaded configuration as the default permanently, the switch must be accessed using the default IP address and the configuration saved.

8.1.12 Physical Reset

A user can load the configuration of the switch to factory defaults using a port loop-back. This also loads the factory default IP configuration. This option may be required if the switch IP address is not known and/or the switch is not communicating over the network. The new configuration is available immediately. The following procedure shows the steps for resetting the factory defaults using loop-back:

- a. Loopback between Port-1 & Port-2 of the main switch using standard Ethernet cable
- b. Power on the board and wait till the Ethernet connection is established
- c. Remove the loopback cable

Note: The factory default configuration is only loaded and not stored. To permanently store this configuration, refer to section 7.1.9.

9. SPECIFICATIONS

The specifications for Epsilon-8130 are summarized in the following table.

Ethernet switch	8-port, layer 2+ switch Built-in 416MHz MIPs 24KEC microcontroller for configuration and management
Number of ports	8 10/100/1000Mbps copper Ethernet ports with non-blocking wire-speed performance
On-board memory	4Mb packet memory Shared memory buffer with per-port and CoS memory management
Frame buffer	Jumbo frame support at all speeds
MEF	Hierarchical MEF compliant policing & scheduling MEF E-Lane, E-Line, and E-Tree services
VLAN	IEEE 802.1Q VLAN switch with 8K MACs and 4K VLANs Push/pop up to two VLAN tags Independent & shared VLAN learning (IVL, SVL)
Multicast	IPv4 and IPv6 multicast group support
DSCP	DSCP remarking for both IPv4 and IPv6 frames
Remarking	Dual leaky bucket policers with remarking and statistics
Classifier	8 priorities and 8 CoS queues per port with strict or deficit-weighted round robin scheduling Shaping / policing per queue and per port
Storm control	Policing with storm control and MC/BC protection
Link aggregation	IEEE 802.3ad
RSTP	Rapid spanning tree protocol (IEEE 802.1W) and MTSP
Security	Advanced security and prioritization available through multistage TCAM engine
Power management	ActiPHY and PerfectReach power management VeriPHY cable diagnostics
Serial port	1 RS-232 for host interface or direct UART TTL support
Indicator LEDs	16 status LEDs, two per port 2 general purpose LEDs
Classifier	Programmable multi-layer classifier with 4 QoS classes
RSTP	Rapid spanning tree protocol (IEEE 802.1W)
Standalone Capable	Can operate as a standalone network switch or in combination with a host computer
Power Input	+5-36V DC/DC power supply
Power consumption	5.4W typical at +5VDC with all 8 ports active, approx. 0.26W less for each inactive port
MTBF	624,170 hours at 20°C
Form factor	PC/104 (3.55" x 3.775") Height: 15.7mm with heatsink
Operating temp	-40°C to +85°C (-40°F to +185°F)
Weight	Approximately 3.5oz (99g) with heatsink
RoHS	Compliant

The timing specifications for the board are summarized in the following table.

Time to Login and alive LED flashing after power-on, power cycle, or reboot	8 sec.
Time for ports to reconnect after power-on, power cycle, or reboot	15 sec.
Time for all ports to start passing data after power-on, power cycle, or reboot	<30 sec. (typical 24-26 sec.)
Time for all ports to start passing data after restoring factory defaults	8 sec.

APPENDIX A SUPPORTED MIBS

Epsilon-8130 supports the following management information bases (MIBs). Each MIB contains definitions and information regarding the properties of managed resources and the services that the agents support.

The following MIBs are supported by Epsilon-8130:

- LLDP
- RFC1213 Interfaces
- RFC1213 System
- RFC1213 SNMP
- RFC1213 IP
- RFC1213 TCP
- RFC1213 UDP
- RFC1213 IGMP Event MIB
- RFC1213 Differentiated Services Architecture MIB
- RFC1213 Event MIB
- RFC4188 Dot1D
- RFC3635 Transmission

APPENDIX B UPGRADING BOOTLOADER & APPLICATION IMAGE

This section provides instructions on how to upgrade the boot loader and application image. The upgrade process has the below main components.

1. Load the new RedBoot image and store it in the flash
2. Create a new file system
3. Create the managed flash file system entries and loading application
4. Create a boot script

The following section describes the procedure step-by-step.

Note: Updating boot loader is optional. If user wants to update only application, skip steps 4-22.

Load the new RedBoot image and store it in the flash.

1. Open TeraTerm and connect to the device using (38400, 8, N, 1).
Note: If upgrading the software from version 1.0.1 to 2.0.0, use (115200, 8, N, 1).
2. Reset the device by power cycle or pressing the reset push-button.
3. Within three seconds press Ctrl-C. This will bring up the RedBoot command prompt.
4. Type the following command

```
load -r -m xmodem -b 0x80040000
```
5. Download the **redboot.bin** file from TeraTerm. Select File > Transfer > XMODEM > Send,
select **redboot.bin** file, and click Open.
6. Wait for the transfer to complete. Make sure that 'Teraterm XMODEM Send' popup window shows 100%.
If not, repeat steps 4 and retry.
7. Create a new redundancy-supporting file system.

```
fis init
```
8. Press y when prompted to continue.
9. Overwrite the current RedBoot image with the new version.

```
fis create -b 0x80040000 -r 0 -l 0x40000 -f 0x40000000 -e 0 RedBoot
```

If the above step not showing the following length incorrect error, skip steps 10-20 and go to step 21.

"Image found, but length is incorrect (present image size 0x20000)"

- Transfer the RAM bootable image to RAM. For this, from redboot prompt, type the following

```
load -m xmodem -r -b 0x80040000
```

- Download the **redboot_ram.bin** file from TeraTerm. Select File > Transfer > XMODEM > Send, select **redboot_ram.bin** file, and click Open.

- Wait for the transfer to complete. Make sure that Teraterm XMODEM send popup window shows 100%. If not, repeat steps 10 and retry.

- Once the transfer is complete, switch over to ram bootloader image by issuing the following command

```
go 0x800400BC
```

Note: if upgrading the software from version 1.0.1 to 2.0.0, need to change the TeraTerm baudrate from 115200 to 38400. Because ram bootloader image is running at 38400 baudrate.

- Interrupt the booting process by entering **Ctrl+C**.

- Issue '**fis init**' command. This will be followed by a confirmation question. Give yes (y).

- Now load the regular **redboot.bin** image to the ram location 0x80080000

```
load -m xmodem -r -b 0x80080000
```

- Select File > Transfer > XMODEM > Send, select **redboot.bin** file, and click Open.

- Wait for the transfer to complete then create a new redundancy-supporting file system.

```
fis init
```

- Press y when prompted to continue.

- Overwrite the current RedBoot image with the new image. Type the following command.

```
fis create -b 0x80080000 -r 0 -l 0x40000 -f 0x40000000 -e 0 RedBoot
```

This will be followed by a confirmation question. Give yes (y).

- Reset the device with the following command.

```
reset
```

- Within three seconds, press **Ctrl-C**.

Create a new file system

- Create a configuration structure entry.

```
mfill -b 0x80040000 -l 0x40000 -p 0xff -1
```

```
fis create -r 0 -e 0 -b 0x80040000 -l 0x40000 -f 0x40040000 conf
```

- Create a stack configuration structure entry.

```
mfill -b 0x80040000 -l 0x100000 -p 0xff -1
```

```
fis create -r 0 -e 0 -b 0x80040000 -l 0x100000 -f 0x40080000 stackconf
```

- Create a syslog entry.

```
fis create -r 0 -e 0 -b 0x80040000 -l 0x40000 -f 0x40180000 syslog
```

Create the managed flash file system entries

26. Load the file ***Epsilon-8100.gz***.

```
load -r -b 0x80040000 -m xmodem
```

27. From TeraTerm, choose File > Transfer > XMODEM > Send..., select *Epsilon-8100.gz*, and click Open.

28. Create the managed and managed.bk file entries.

```
fis create -r 0x80040000 -e 0x800400bc -l 0x600000 -f 0x401c0000 managed
```

```
fis create -r 0x80040000 -e 0x800400bc -l 0x600000 -f 0x407c0000 managed.bk
```

Note: File names managed and managed.bk must not be changed. The upgrade function of the application relies on these names.

Create a boot script

29. Start a new script.

```
fconfig -i
```

30. Press y when prompted to continue. This will show "Run script at boot: false" selection.

31. Change 'false' to 'true' for the selection "Run script at boot: false" and Hit <Enter> Key

32. Enter the following commands

```
fis load -d managed
```

```
go
```

```
fis load -d managed.bk
```

```
go
```

33. Hit <Enter> Key. This will show "Boot script timeout (1000ms resolution): 0" selection.

34. Change '0' to '3' for the selection "Boot script timeout (1000ms resolution): 0".

35. If the application software version is 2.0.0 or above , Set the baud rate to 38400 in the selection "Console baud rate: 38400". else use 115200.

36. Press y to when prompted to continue.

37. Reset the device with the following command.

```
reset
```

APPENDIX C CHANGES FROM EPS-8100 TO EPS-8130

Item	Changes	Reason for Change	EPS-8100 vs EPS-8130
1	Updated 3.3V power section	Power section is redesigned for better manufacturability	Changed TPS54540 to LM22679TJE-ADJ/NOPB Input supply range is same as EPS-8100 (+5V to +36V)
2	Updated 2.5V power section	Power section is redesigned for better manufacturability	Changed EN5337QI to RT8073GSP
3	Updated 1.0V power section	Power section is redesigned for better manufacturability	Changed EN5366QI to RT8073GSP
4	Updated 1.8V power section	Power section is redesigned for better manufacturability	Changed AP7167-SPG-13 to MIC49150YMM
5	Updated the magnetics part in the design	Used a cost-effective part with better availability.	Changed the magnetics from TG111-E12NYNRLTR to LP82461ANL. Both the parts are footprint and functionally compatible and hence backward compatibility to EPS-8100 is still maintained.
6	Changed LED status connector J13 to 2x17 pin header instead of S30B-PUDSS-1(LF)(SN)	S30B-PUDSS-1(LF)(SN) part is difficult to purchase. Hence used pin header for better availability.	This 34-position pin header provides access to ethernet LED signals for each of the eight ports. The pinout is same as 30 pin EPS-8100 connector by keeping extra 4 pins NC (no connect) in EPS-8130. DSC cable 6981509 or a common 2mm pitch 2x17 ribbon cable can be provided to the customers who intend to make use of these signals.
7	Added a build option to support TTL logic level signals for the RS-232 port.	Added as an alternate support in case of any customer requirements.	EPS-8130 has support to direct TTL logic or RS-232 mode with no hardware flow control. Logic level signals can provide extended support for any physical signal levels like RS-232/ RS-485/ RS-422 with the use of an appropriate transceiver.
8	Provided separate GPIO for restoring the default settings	Pin assigned for this feature in EPS-8100 had dual functionality and had logic conflict between LED pattern and restore default settings.	EPS-8130 supports restoring the factory configuration setting with the use of upgraded firmware. The functionality of the signal #DEFAULT connected to the J15 pin header is as follows: * Driven LOW (0): Restore factory configuration settings * Driven HIGH (1): Save configuration settings The firmware of EPS-8100 can be used if this functionality is not mandatory.
9	Added test points for power	Test points are one of the standard ways to easier the debugging.	Test points are placed at the board edge to facilitate easier testing and debugging.
10	Heat Sink redesign	To facilitate the component placement for the new design	The dimension of the heat sink designed for EPS-8130 is 51x45 mm whereas the one used for EPS-8100 is 55x40mm