



 = Default Jumper Settings













810520 REV A  
PROMETHEUS PANEL I/O BOARD  
(C) 2001 DIAMOND SYSTEMS CORP.  
FILE PANELV2.PCB  
6-22-01

TOP ASSEMBLY DRAWING






810520 REV A  
 PROMETHEUS PANEL I/O BOARD  
 (C) 2001 DIAMOND SYSTEMS CORP.  
 FILE PANELV2.PCB  
 6-22-01


BOTTOM ASSEMBLY DRAWING




HOLD DURING BOOT  
FOR ZFIX CONSOLE




MAIN POWER I/O








CONNECT TO J1M  
SCREW TERMINALS



AUX JUPITER INPUT



CONNECT TO J11  
FOR MAIN POWER



Diamond Systems Confidential


Diamond Systems Corporation  
10000 Wilshire Blvd., Suite 1000  
Beverly Hills, CA 90210, USA  
Tel: (650) 813-1100 Fax: (650) 813-1139

CPU PANEL BOARD



Drawn: SJH File: PANEL.V2.SCH

Eng: SJH Date: 6/14/01

Sheet: 1 of 2 Size: Revision: 2




ANALOG/DIGITAL I/O



USB-GLINKS-STR

JUMPER 1 TO 3 AND 2 TO 4  
FOR AMPRO VIDEO.  
JUMPER 3 TO 5 AND 4 TO 6  
FOR OTHER (SWAP SYNC'S)



FOR AMPRO VIDEO

